

BACK-UP ALARMS



60 Series

61-Series

62-Series

- IMPORTANT:** Please read all of the following instructions before installing your new Star back-up alarm. This instruction sheet applies only for installation of the models listed at the top of this sheet **on negative ground vehicles only.**
- CAUTION:** All of our DC powered back-up alarms are polarity sensitive. All wires connected to the positive terminal of the battery should be fused at the battery for their rated load. **Testing the alarm before this fuse is properly installed will void the warranty on the alarm.**
- Mount the alarm in the rear of the vehicle with the sound opening outward towards the hazard zone.
- Connect the black wire to the negative side of the battery or a good chassis ground.
- Connect the red wire to an independent actuating switch or splice it into the back-up lights as shown in the diagram on the reverse side of this page. **Please Note:** *The vehicles supply voltage must be the same as the voltage rating specified on the alarm you are installing. Any other voltage applied will void the warranty.*
- For models with a Brown Wire:** If you ordered a model with a selectable decibel level (60-802S, 60-907S, 62-802S, or 62-907S), connect the brown wire with the red wire (BAT +) for the lower dB output, or cut it short and tape it off for the higher dB output. An optional switch may be installed to allow the driver to select which level the back-up alarm operates at.

ONE YEAR LIMITED WARRANTY

The manufacturer warrants each new product, under normal use, against factory defects in material and workmanship for one year after the date of purchase. The owner will be responsible for returning to the Service Center any defective item(s) with the transportation costs prepaid. The manufacturer will, without charge, **repair or replace at its option**, products, or part(s), which its inspection determines to be defective. Repaired or replacement item(s) will be returned to the purchaser with transportation costs prepaid from the service point. A copy of the purchaser's receipt must be returned with the defective item(s) in order to qualify for the warranty coverage.

Exclusions from this warranty include, but are not limited to, bulbs, strobe tubes, domes, and/or the finish. This warranty shall not apply to any light, which has been altered, such that in the manufacturer's judgment, the performance or reliability has been affected, or if any damage has resulted from abnormal use or service. This warranty does not apply to defect or damage occurring as a result of disaster, accident, abuse, misuse, lightning, power surges, or failure to follow instructions in any enclosed manuals. Any damage or defects occurring as a result of any unauthorized service or repairs by unauthorized persons shall be excluded from this warranty.

There are no warranties expressed or implied (including any warranty of merchantability or fitness), which extend this warranty period. **The loss of use of the product, loss of time, inconvenience, commercial loss or consequential damages, including costs of any labor, are not covered.** The manufacturer reserves the right to change the design of the product without assuming any obligation to modify any product previously manufactured.


This warranty gives you specific legal rights. You might also have additional rights which may vary from state to state. Some states do not allow limitations on how long an implied warranty lasts. Some states do not allow the exclusion or limitation of incidental or consequential damages. Therefore, the above limitation(s) or exclusion(s) may not apply to you.

Model #	Voltage	Current	Decibels	Housing
60-087	12-36VDC	0.3 a	87	Die Cast
60-097	12-36VDC	0.3 a	97	Die Cast
60-102	12-36VDC	0.3 a	102	Die Cast
60-107-12	12V ONLY	0.7 a	107	Die Cast
60-107-24	24-36VDC	0.3 a	107	Die Cast
60-097DT	12-36VDC	0.3 a	97	Die Cast
60-102DT	12V ONLY	0.7 a	102	Die Cast
60-707A	12-24VDC	0.3 a	77-97	Die Cast
60-802A	12-24VDC	0.3 a	87-102	Die Cast
60-807A	12V ONLY	0.7 a	87-107	Die Cast
60-802S	12-36VDC	0.3 a	87 or 102	Die Cast
60-907S	12V ONLY	0.7 a	97 or 107	Die Cast
61-107	12-36VDC	0.3 a	107	Die Cast
61-112	12-36VDC	0.3 a	112	Die Cast
62-087	12-36VDC	0.3 a	87	ABS
62-097	12-36VDC	0.3 a	97	ABS
62-102	12-36VDC	0.3 a	102	ABS
62-107-12	12V ONLY	0.7 a	107	ABS
62-107-24	24-36VDC	0.3 a	107	ABS
62-097DT	12-36VDC	0.3 a	97	ABS
62-102DT	12V ONLY	0.7 a	102	ABS
62-707A	12-24VDC	0.3 a	77-97	ABS
62-802A	12-24VDC	0.3 a	87-102	ABS
62-807A	12V ONLY	0.7 a	87-107	ABS
62-802S	12-36VDC	0.3 a	87 or 102	ABS
62-907S	12V ONLY	0.7 a	97 or 107	ABS

DT = Dual-Tone

A = Auto Adjusting

S = Selectable Decibel Level



If you have any questions concerning this or any other Star product, or need warranty service, please contact our Customer Service Department at (585) 226-9787.

Star Headlight & Lantern Co., Inc.

455 Rochester Street Avon, NY 14414

Phone: 585-226-9787 FAX: 888-478-2797



www.starheadlight.com